








# PS753\_PS753,V1



## Firmware(FW) Update Manual

### 1 Device and Tool Preparation

1.1 Please prepare following devices and tools before FW upgrade.


PS753	PC or Laptop	Monitor
	 or 	
Power adapter and power cord	Ethernet cable	HDMI Cable
		

1.2 Please confirm the hardware version and select the correct firmware before updating.


Model	PS753	PS753,V1
Label		
SN	P13xxxxxx	P14xxxxxx
FW Version	PVXxxx_PVYxxx	PWAxxx_PVYxxx

## 2 Connections

### 2.1 Connecting via switch or router.




### 2.2 Connecting monitor.



## 3 FW Download

### 3.1 Open browser and enter the IP address of the camera in the address bar.


You can check the IP address from [Menu]> [Settings]> [Control]> [IP Address].




### 3.2 Enter the account and password to log in webpage.

Account: admin


Password: 9999(Default)




3.3 Select [Maintenance]> [File Select] to select firmware file and press [Upgrade].



3.4 FW download starts, please don't close the page. (Around 3 minutes taken)



3.5 FW upgrade is progress and please follow HDMI OSD message.  
When finished, the camera will reboot.



### 3.6 Login webpage again and check the FW version from [About]> [Firmware Version]

