


VC-A53 Firmware(FW) Upgrade Instruction

1 Device and Tool Preparation


1.1 Please prepare following devices and tools before FW upgrade.

Camera	PC or Laptop
	
Power adapter and power cord	Ethernet cable
	

2 Connections


2.1 Connecting via switch or router

2.1.1 Please ensure the [Ethernet]> [DHCP] in the menu is ON.



3 FW Download


- 3.1 Open browser and enter the IP address of the camera in the address bar.
You can check the IP address from [Status]> [Ethernet] in the menu.




- 3.2 Enter the account and password to log in webpage.
Account: admin
Password: 9999(Default)

A screenshot of a login page. At the top, it says 'Sign in to access this site'. Below that, a message reads: 'Authorization required by http://192.168.4.163 Your connection to this site is not secure'. There are two input fields: 'Username' with the text 'admin' and 'Password' with four dots. Below the password field is a blue button labeled 'Sign in' which is highlighted with a red box, and a grey button labeled 'Cancel'.


- 3.3 Select [Maintenance]> [...] to select firmware file and press [Upgrade].




3.4 FW download starts. (Around 2 minutes taken)




3.5 FW upgrade is successful, click [OK] and the camera will reboot.



3.6 Please Login and go [Maintenance]> [Reset] and do the [Factory Reset] to ensure the procedure is completed.



3.7 Click [Yes] and the unit will do the factory reset.



3.8 Login webpage again and check the FW version from [About]> [Firmware Version]

