# VC-B50U_VC-B70U
# Firmware(FW) Update Manual

## 1 Device and Tool Preparation

1.1 Please prepare following devices and tools before FW upgrade.

| VC-B50U_VC-B70U | PC or Laptop |
|---|---|
| | or |
| **Power adapter and power cord** | **Ethernet cable** |
| | |

## 2 Connections

2.1 Connecting via switch or router.



## 3 FW Download

3.1 Open browser and enter the IP address of the camera in the address bar.
You can check the IP address from [Status]> [Ethernet] in the menu.




3.2 Enter the account and password to log in webpage.
Account: admin
Password: 9999(Default)




3.3 Select [Maintenance]> […] to select firmware file and press [Upgrade] and [Yes].






3.4 FW download starts, please don't close the page. (Around 2-3 minutes taken)






3.5 Login webpage again and check the FW version from [About]> [Firmware Version].