

# CL510 Quick Start Guide

**Lumens™**

## ▼Menu

Open setting menu /exit the menu

## ▼Up / Down / Left / Right

Press Left/Right/Up/Down button to select required function

## ▼Enter

Enter/Activate functions

## ▼Laser

Switch on/off laser mark

## ▼Capture

Capture the image to internal memory

## ▼Record

Record motion images, press [RECORD] to record images into the internal memory; Press [RECORD] again to stop

## ▼DEL

Delete images in the internal memory

## ▼PAN


Enable/Disable the Partial Enlarged mode

## ▼Mask

Enter Mask/Spotlight mode

## ▼Photo/Text

Select image mode (Photo/Text/Gray)



## ▼Power

Switch on/off the power

## ▼Auto Tune

Automatically adjust to the optimal brightness and focal length of images

## ▼Zoom +/-

Zoom in and out the image

## ▼BRT +/-

Adjust the brightness of the image

## ▼Freeze

Freeze the current image on the screen. Press again to defreeze

## ▼Auto Focus

Automatically adjust the focal length of the image

## ▼Rotate

Rotate the image by 0°/90°/180°/270°

## ▼Playback

Read files stored in the internal memory

## ▼PIP

Compare images (Compare live images with stored images)

## ▼Slide Show

Show the photos or videos in the internal memory in Slide mode