VC Series Quick Installation Guide




1. I would like to install Camera on the ceiling


1.1 Prepare for the parts and equipment required during the installation

- Accessories of Camera in the box (metal plates A, B, M3 screw silver x 8, black x 2)
- Screw for locking on ceiling mounted hanger x 4
- ▶ Drilling machine, screw driver, ladder

1.2 Installation steps

- Please adjust resolution on DIP Switch at first.
 (Please refer to <u>2. Instruction on DIP SWITCH Setting</u>)
- **2.**Fix the metal plate A on the machine base with 4 M3 silver screws.





3.Lock the metal plate B on ceiling mounted hanger

- **%**Caution:
- *Please use the hanger that has obtained UL security approval.
- *Please reserve the hole for the connecting wires of the camera.
- ${f 4.}$ Combine the metal plate A and the metal plate B
 - ▶ Push the metal plate A up to the ceiling and then to the right to latch the metal plate B.
 - ▶ And then secure with 2 M3 silver screws and 1 M3 black screw.

2.Instruction on DIP SWITCH Setting

2.1 OUTPUT SWITCH



Output Mode	Setting
1920x1080/60p	
1920x1080/50p	
1920x1080/30p	
1920x1080/25p	
1920x1080/60i	
1920x1080/50i	
1280x720/60p	
1280x720/50p	
1280x720/30p	
1280x720/25p	
1080/59.94p	
1080/59.94i	
1080/29.97p	
720/59.94p	
720/29.97p	

2.2 IR SELECT



ID	Setting
1	
2	
3	

2.3 Camera Address Selector



Setting	Function Descriptions
0~7	ID 0~7
8~9	Reserved

2.4 System Switch




Setting	Function Descriptions
DIP 1	RS-232C/RS-422 selector OFF: RS-232C / ON: RS-422
DIP 2	Infrared signal output switch OFF: Off / ON : On
DIP 3	Communication baud rate selector OFF: 9600 / ON : 38400
DIP 4	Reserved



3. Single Camera Connection

Device List

- •Lumens Camera(such as VC-A60S.VC-A50S,VC-G30,VC-G50...) x1
- VC-HDTX(Optional) x1
- VC-HDRX(Optional) x1
- •VS-K20(Optional) x1
- Monitor x1



4. Multi-Camera Connection

Device List

- •Lumens Camera(such as VC-A60S.VC-A50S,VC-G30,VC-G50...) x1-7
- •VC-HDTX(Optional) x1-7
- VC-HDRX(Optional) x1-7
- •VS-K20(Optional) x1
- Monitor x1
- ●VC-AC07 x1-6

